



PHILCO

Car Radio Service Bulletin No. 2a

Published by the Philco Radio & Television Corporation of Great Britain, Ltd., Perivale, Greenford, Middlesex

Data of Accessories and Contents of Kit Envelopes Supplied with Current Models

Models 901T, 901S, K 627T, K 627S

CONTENTS.	PART NO.	LIST PRICE.
1 Control Head with 32" shafts	420-5026	40/-
1 " F " Kit	400-8005	9d.
1 " C " Kit	400-9000	16/7
1 " G " Kit	400-8006	2/6
1 " J " Kit	400-8004	1/6
1 Template	390-3226	—
1 Guarantee card	390-3213	—
	K627T & S; 390-3371	
1 All-wave aerial book	390-3230	—
1 Aerial lead	410-3002	2/6
1 Battery cable	410-3001	3/-

Model 901T (Chrysler and Dodge)

1 Control Head with 21" shafts	420-7011	40/-
1 " F " Kit	400-8005	9d.
1 " C " Kit (special)		13/11
1 " J " Kit	400-8004	1/6
1 " G " Kit	400-8006	2/6
1 Battery cable	410-3013	2/3
1 Aerial lead	410-3002	2/6
1 Guarantee card	390-3213	—
1 Template	390-3226	—

Model 902SF (Ford)

1 Control Head with 21" shafts	420-7011	40/-
1 " F " Kit	400-8005	9d.
1 " C " Kit (special)		16/7
1 " G " Kit	400-8006	2/6
1 " H " Kit	400-8003	9d.
1 Aerial lead	410-3009	2/6
1 Battery cable, 9"	410-3013	2/3
1 Cable threader	380-5295	Doz. 6d.
1 Guarantee card	390-3359	—
1 Template	390-3226	—

Models 902T and 902S

As for Models 901 T and S, with the addition of:—		
1 Plain envelope containing		Each 1d.
4 Speaker clamps	280-1274	
4 Screws	W.B.1136	Doz. 6d.

Kit Contents

CONTENTS.	PART NO.	LIST PRICE.
" F " Kit Fuse Insulator	400-8005 5676 270-2056	9d. 5d. Doz. 3d.
" G " Kit 3 Studs ($\frac{3}{8}$ B.S.F.) 6 Nuts ($\frac{3}{8}$ B.S.F.) 3 Washers (Large) 3 Washers 3 Lockwashers (Outside) 3 Lockwashers (Inside)	400-8006 W.B. 1127 W.N. 1122 290-1158 W.W. 1109 W. 338 W. 679	2/6 Each 4d. ,, 1d. ,, 3d. Doz. 4d. ,, 2d. ,, 2d.
" H " Kit 1 Mounting bracket 2 Studs 2 Nuts 2 Lockwashers	400-8003 290-1114 W.B. 203 W.N. 200 W. 752	9d. Each 3d. ,, 2d. Doz. 7d. ,, 2d.
" C " Kit, for 901 Series 1 Distributor Suppressor 2 .5 mf. Condensers 1 1 mf. Condenser (steel or brass case)	400-9000 4851 30-4007 4522	16/7 1/3 2/8 2/5
" C " Kit for Chrysler and Dodge Cars Same as " C " Kit, but omit:— 1 .5 mf. Condenser	30-4007	13/11
" C " Kit for 902 S.F. (Ford cars) Same as " C " Kit, but omit:— 30-4007 and 4851 Condensers Add:— 2 Condensers 3 Condensers 1 Kalon Screw	300-4028 300-4027 W. 454	18/6 Each 2/- ,, 2/3 1d.
" J " Kit 1 Strap assembly 1 Steering column band 1 Tension screw 1 Pressure plate 1 Felt strip 2 Screws	400-8004 290-1115 290-1116 W.B. 010 290-1117 270-7141 W.B. 328	Each 1/6 ,, 5d. ,, 3d. ,, 3d. ,, 1d. Doz. 6d. ,, 2d.