

PHILCO AUTO RADIO

MOPAR SKYWAY ANTENNA FOR 1940, 1941 AND 1942 CARS
CHRYSLER PART Nos. 981434 & 981435

PHILCO PART Nos. 91-0232, 91-0234, 91-0235

PARTS LIST

| | |
|--------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| 1. Antenna Rod Assy. 66 Inch (For 91-0232 Antenna) 77-1055 66 Inch (For 91-0234 Antenna) 77-1167 100 Inch (For 91-0235 Antenna) 77-1089 | 8. Lockwasher97-0231 |
| 2. Lower Mounting Cap For 91-0232, 91-0234 Antenna 57-2362 For 91-0235 Antenna57-2650 | 9. Hex Nut97-0256 |
| 3. Upper Mounting Cap (Angle Cap) For 91-0234 Antenna57-1360 For 91-0235 Antenna57-2496 | 10. Brass Plug57-2701 |
| 4. Upper Mounting Cap (Straight) For 91-0232, 91-0234 Antenna 57-2362 For 91-0235 Antenna57-2650 | 11. Lower Eyebolt For 91-0232, 91-0234 Antenna 97-0230 For 91-0235 Antenna97-0271 |
| 5. Insulator55-1253 | 12. Upper Eyebolt (Used with Angle Mounting Cap) For 91-0234 Antenna97-0272 For 91-0235 Antenna97-0276 |
| 6. Rubber Washer55-1586 | 13. Upper Eyebolt (Used with Straight Mounting Cap) For 91-0232, 91-0234 Antenna 97-0230 For 91-0235 Antenna97-0271 |
| 7. Rubber Gasket55-1254 | 14. Lead In95-0231 |
| | 15. Ball Tip55-1482 |

INSTALLATION INSTRUCTIONS

1. Remove left cowl trim panel.
2. Select proper template, center punch, and drill two 1/2" holes in left cowl panel as indicated on template.
3. Remove insulating material from around holes in cowl panel.
4. Remove nuts and lockwashers from threaded mounting sleeves.
5. **IMPORTANT:** On 1940 Plymouth models, replace upper stanchion angle cap and eyebolt with extra cap and eyebolt furnished in antenna package. (See "TOP STANCHION" illustration at left).
6. Insert threaded sleeves through holes in cowl and replace lockwashers and nuts on sleeves. Tighten securely.
7. Connect antenna lead to lower stanchion sleeve as shown in "BOTTOM STANCHION" illustration at left.
8. Plug antenna lead into radio.
9. Replace cowl trim panel.

CAUTION — DO NOT STRETCH ANTENNA LEAD WIRE DURING INSTALLATION.

NOTE — Chrysler Part No. 981434 corresponds to Philco Part Nos. 91-0232 and 91-0234. The 91-0232 antenna is for use on 1940, 1941 and 1942 cars. The 91-0234 antenna is for use on 1942 cars.

Chrysler Part No. 981435 corresponds to Philco Part No. 91-0235. The 91-0235 antenna is for use on 1942 cars.

