


# PHILCO AUTO RADIO

## STANDARD CONTROL MODELS 926 - 927 - 928K



## STANDARD CONTROL MODELS 926 - 927 - 928K

### PARTS LIST

PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
L-3111	Cable	28-4500	Washer	28-7298	Top Cover
W-601	Screw	28-5753	Stop	28-8711	Spring
W-1755	Screw	28-5754	Gear Follower	28-8871	Flexible Shaft
3093	Washer	28-5810	Gear	28-8872	Anti Backlash Spring
4169	Washer	28-5848	Washer	28-8874	Spring
27-4265	Rubber Sleeve	28-6216	Pin	33-5268	Volume Control & Switch Assembly
27-4725	Knob	28-6833	Tuning Shaft End	34-2040	Pilot Lamp
27-5399	Dial	28-6834	Gear	38-5380	"A" Lead
27-7133	Ferrule	28-6838	Bushing	38-7734	Pilot Lamp Assembly
28-1270	Housing	28-6839	Pin	42-5840	Control Assembly
28-2043	Washer	28-6848	Dial Shaft	42-5842	Cord
28-2815	Clamp	28-6849	Dial Spacing Bushing	42-5846	Drum
28-4187	Washer	28-7297	Bottom Cover	42-5849	Tuning Shaft & Knob End Assembly