

PHILCO 1941 HOME RADIO SPEAKERS

With Replacement Cones

Listed below are the Philco speakers and replacement cones used in the 1940 and 1941 Philco home and auto radio line.

In some models two or more different type speakers are used. These speakers, however, are interchangeable and will have the same part number, with the exception of a suffix number -1, -2, etc., added to the part number. The cone assemblies of these speakers are not interchangeable.

It is important when ordering cone assemblies that the correct part number, as indicated on these pages, be specified.

SPEAKER	REPLACEMENT CONE	USED IN MODELS	SPEAKER	REPLACEMENT CONE	USED IN MODELS
36-1504-2	36-4126	41-712-714	36-1519-3	36-4166	
36-1505-1	36-4115	41-705C	36-1519-4	36-4172	
36-1506-1	36-4158	41-84	36-1520-4	36-4180	41-708
36-1507-1	36-4158	41-90-95-100-105	36-1521-3	36-4175	PT87
36-1507-3	36-4165		36-1522-4	36-4171	41-110K
36-1508-3	36-4161	41-745-759	36-1523-2	36-4173	41-285-287-290
36-1509-3	36-4162	41-713	36-1524-4	36-4178	41-610-611
36-1510-3	36-4163	41-230-235	36-1525-9	36-4182	PT30
36-1510-4	36-4168		36-1526-3	36-4175	41-841
36-1511		41-105	36-1527-2	36-4179	HR1
36-1512-9	36-4167	41-225	36-1528-4	36-4176	41-608-609
36-1513-3	36-4164	41-260	36-1528-9	36-4203	
36-1513-4	36-4169		36-1530-4	36-4181	41-616PM
36-1514-2	36-4173	41-280XF	36-1532-2	36-4193	41-909
36-1514-4	36-4170		36-1533-9	36-4190	41-PT2
36-1514-9	36-4192		36-1534-3	36-4187	41-695
36-1515-2	36-4173	41-295X	36-1535-4	36-4196	41-285-287-290
36-1515-4	36-4181		36-1536-2	36-4194	41-908
36-1516-3	36-4165	41-603	36-1537-4	36-4197	41-620
36-1517-2	36-4132	41-89	36-1538-3	36-4165	41-623
36-1518-3	36-4200	41-604	36-1540-3	36-4201	41-842
36-1518-4	36-4171		36-1541-9	36-4199	41-601
36-1519-2	36-4202	41-250-255	36-1542-9	36-4204	41-PT91