

INDEX

Home Radio Models

MODEL	PAGE
41-KR	46
41-PT-2	32, 33
41-PT-4	32, 33
41-PT-6	32, 33
41-PT-10	34, 35
41-PT-12	34, 35
41-PT-30	36, 37
41-PT-42	36, 38
41-PT-44	36, 38
41-PT-49	36, 37
41-PT-87	36, 39
41-PT-89	40, 47
41-RP-1	41
41-RP-2	42
41-RP-5	43
41-RP-6	44
41-RP-15	45
41-22CL	59, 60
41-81	47, 49
41-83	47, 50
41-84	47, 51
41-85	52
41-90	48, 53
41-95	48, 54
41-100	48, 55
41-105	48, 56
41-110	57, 58
41-220	59, 60
41-221	61, 62
41-225	59, 60
41-226	61, 62
41-230	63, 64
41-231	65
41-235	63, 64
41-240	66, 67, 69
41-245	66, 68, 69
41-246	70, 71
41-250	72, 73
41-255	72, 73
41-256	74, 75
41-258	76, 77
41-260	78, 79, 81, 82
41-265	78, 80, 81, 82
41-280	83, 84, 85, 86
41-285	83, 84, 85, 86
41-287	83, 84, 85, 86
41-290	83, 84, 85, 86
41-295	87, 88, 89, 90
41-296	83, 84, 85, 86

MODEL	PAGE
41-315	87, 88, 89, 90
41-316	91 to 96
41-695	181, 184
41-705	157, 158, 159, 160
41-708	157, 158, 159, 160
41-712	161, 162, 163, 164
41-713	161, 162, 163, 164
41-714	165, 166
41-722	167, 168, 169, 170
41-745	171, 172, 173, 174
41-758	167, 168, 169, 170
41-759	171, 172, 173, 174
41-788	175 to 180
41-841	181 to 184
41-842	185, 186
41-843	185, 186
41-844	185, 186
41-851	181 to 184
41-908	187, 188
41-909	187, 188
41-910	188

Radio-Phonograph Models

MODEL	PAGE
41-HR-1	97, 98
41-601	99, 100
41-602	101, 102
41-603	103, 104, 105, 106
41-604	103, 104, 105, 106
41-605	103, 104, 105, 106
41-607	103, 104, 105, 106
41-608, Code 121	107 to 110
41-609, Code 121	107 to 110
41-608, Code 122	111 to 114
41-609, Code 122	111 to 114
41-610	115, 116, 117, 118
41-611	115, 116, 117, 118
41-616	119 to 124
41-620	125, 126
41-623	127, 128, 129, 130
41-624	127, 128, 129, 130
41-625	127, 128, 129, 130
41-629	131, 132, 133, 134
41-695	181, 184
Automatic Record Changers	
Part No. 35-1231, 35-1233,	
35-1239, 35-1266, 35-1268,	
35-1269, 35-1276, 35-1279,	
	135 to 144

MODEL	PAGE
DeLuxe Intermix Automatic Record Changers Part No. 35-1234, 35-1236	145 to 156

Auto Radio Models

MODEL	PAGE
AR-10	189, 190, 219
AR-40	191, 192, 203, 204, 219
AR-45	193, 194, 203, 204, 219
AR-50	195, 196, 203, 204, 219
AR-55	197, 198, 203, 204, 219
AR-65	199, 200, 203, 204, 219
AR-75	201, 202, 203, 204, 219
C-1808	220 to 226
C-1809	220 to 224
F-1840	226 to 230, 235 to 238
F-1841	231 to 238
P-1830	239, 240, 245 to 248
P-1835	241 to 248
S-1825	249 to 252, 261 to 264
S-1824	257 to 264
S-1826	253 to 256, 261 to 264
SW-1	205, 206, 207, 208
822P	209, 210, 211, 212
822PV	209, 210, 213, 214
Installing Instrument Board	
Speaker in 1941 Cars	215 to 218
Replacement Cones — 1941	
Auto Radios	265

Miscellaneous Items

	PAGE
Aerials	11, 12, 219
Bakelite Cabinets	29, 30
R. M. S. Service Supplies	13, 14
Simplified Radio Testing	3, 4, 5
Sound Amplifiers	9, 10
Speaker Cones	31
Setting and Operating Electric Push-button Tuning	27, 28
Tube Information	15 to 26
Test Instruments	6, 7, 8
Tools	10