

TABLE OF CONTENTS

	Page
INTRODUCTION	ii
1952 RADIOS AND RADIO-PHONOGRAPHS	
Model	
52-540	1
52-540-I	1
52-541	1
52-541-I	1
52-542-I	1
52-544	7
52-544-I	7
52-544-W	7
52-548	11
52-543	15
52-545	15
52-547	15
52-550	15
52-640	19
52-641	19
52-643	23
52-549	27
52-642	27
52-939	27
52-940	31
52-941	31
52-942	31
52-944	35
52-1340 (Codes 121 and 122)	41
52-1730	45
52-1731	49
52-1736	49
52-1733	57
1952 TROPIC RADIOS AND RADIO-PHONOGRAPHS	
Model	
3022 (Codes 121 and 122)	67
3214	71
3421	77
3472	83
3123	83
RECORD CHANGER	
Model	
M-22	87