

TABLE OF CONTENTS



INTRODUCTION	
1953 RADIOS AND RADIO-PHONOGRAPHS	
Model	
53-559	5
53-560	9
53-561	13
53-562	13
53-563	19
53-564	13
53-565	23
53-566	27
53-651	31
53-652	37
53-656	43
53-658	43
53-700	48
53-701	48
53-701X	53
53-702	57
53-706	57
53-707	57
53-800	62
53-804	63
53-950	69
53-954	69
53-956	75
53-958	82
53-960	91
53-1350	97
53-1750	101
53-1754	105
1953 TROPIC RADIOS AND RADIO-PHONOGRAPHS	
Model	
3474	112
RECORD CHANGER	
Model	
M-24	119