

Philco Radio & Television Corp.

	Model: 40-180	Chassis:	Year: Pre August 1939			
	Power:	Circuit:	IF:			
	Tubes:					
	Bands:					
Resources						
Riders Volume 10 - PHILCO 10-16						
Riders Volume 12 - PHILCO 12-18						
Riders Volume 12 - PHILCO 12-22						
Riders Volume 12 - PHILCO 12-23						
Riders Volume 10 - PHILCO 10-29						
Riders Volume 10 - PHILCO 10-30						
Riders Volume 10 - PHILCO 10-31						

MODELS 39-30,39-35
 MODELS 40-150,40-155
MODEL 40-160
 MODELS 40-180,40-185,40-190
 MODELS 40-195,40-200

PHILCO RADIO & TELEV. CORP.

MODEL 108
 Tuner Data
 MODELS 40-120,40-125
 Alignment, Trimmers

EQUIPMENT REQUIRED: MODELS 40-120,40-125.

(1) Signal Generator; Philco Model 077 Signal Generator which has a fundamental frequency range from 115 to 36,000 K. C. is the correct instrument for this purpose.

(2) Output Meter; Philco Models 027 or 028 Vacuum Tube Voltmeters and Circuit Testers incorporate a sensitive output meter and are recommended.

(3) Philco Fiber Handle Screw Driver, Part No. 45-2610.
 Aligning adapter Part No. 45-2767.

OUTPUT METER: The Philco 027 or 028 Output Meter is connected to the plate and screen terminals of the type 35A5 tube and adjusted for the 0 to 30 V. A. C. scales.

SIGNAL GENERATOR				RECEIVER			SPECIAL INSTRUCTIONS
Operations in Order	Output Connections to Receiver	Dummy Antenna Note A	Dial Setting	Dial Setting	Control Settings	Adjust Compensators in Order	
1	7C7 See Note C	.1 mfd.	455 K. C.	550 K. C.	Vol. Cont. Max.	14A, 14B, 15A	Push "IN" Manual Button Model 40-125
2	Ant. Ter.	10 mmf.	1600 K. C.	1600 K. C.	Vol. Cont. Max.	.2B	See Note B See Note C
3	Ant. Ter.	10 mmf.	1400 K. C.	1400 K. C.	Vol. Cont. Max.	2A	

NOTE A — The "Dummy Antenna" consists of a condenser connected in series with the signal generator output lead (High side). Use the capacity or resistance as specified in each step of the above procedure.

NOTE B — DIAL CALIBRATION: In order to adjust the receiver correctly, the dial must be aligned to track properly with the tuning condenser. To do this, proceed as follows: Turn the tuning condenser to the maximum capacity position (plates fully meshed). With the condenser in this position, the tuning pointer is set horizontal at the low frequency end of the scale (540 K. C.).

NOTE C — COMPENSATORS: Compensators 2A and 2B are at the top of the tuning condenser. Compensator 2A is on the front section and compensator 2B on the rear section. When padding the I. F. the signal generator can be attached to the 7C7 grid on the front section of the tuning condenser.

Adjusting Push Button Tuning - MODELS 39-30,39-35,108 (CODE 121); 40-150,40-155; 40-160; 40-195,40-200,40-180,40-185,40-190. (FOR BUTTON ADJUSTMENT FREQUENCIES FOR MODELS 39-30,39-35, & 108 (CODE 121); SEE PARTS LISTS OF THESE MODELS).

In order to adjust the electric push buttons accurately for reception of broadcast stations, a vacuum tube voltmeter such as Philco Model 027 and 028 should be used. In addition, an insulated padding screw driver part No. 45-2610 and Loktite aligning adapter part No. 45-2767 are required. With this equipment at hand proceed as follows:

Insert the station call letters into the windows above the buttons. The station with the lowest frequency is placed in the first button on the left and the highest frequency is placed in the button on the extreme right. Each push button is adjusted by two set screws located on the rear of the push button unit. Each set of screws is numbered and covers a frequency range as follows:

MODEL 40-160

Push Button	Frequency Range
1	540-1000 K.C.
2	650-1100 K.C.
3	740-1300 K.C.
4	900-1500 K.C.
5	1100-1600 K.C.

MODELS 40-195, 40-200

Push-Button	Frequency Range
1, 2, 3	540-1030 K. C.
4, 5	670-1160 K. C.
6, 7, 8	900-1600 K. C.

MODELS 40-150,40-155,40-180,40-185,40-190.

Push-Button	Frequency Range
1, 2, 3	540-1000 K. C.
4, 5	650-1110 K. C.
6, 7	920-1600 K. C.

Looking at the front of the cabinet, the first button on the

VACUUM TUBE VOLTMETER: To use the vacuum tube voltmeter as an alignment indicator make the following connections:

Remove the 7C6 tube from its socket and insert the aligning adapter, Part No. 45-2767, then replace the tube in the adapter. Connect the negative terminal of the vacuum tube voltmeter to the wire which protrudes from the side of the adapter. Attach the positive terminal of the voltmeter to the chassis. The positive terminal is connected to the chassis.

After connecting the output meter, adjust the compensators in the order as shown in the tabulation below. Locations of the compensators are shown on Fig. 2. If the output meter pointer goes off scale when adjusting the compensators, reduce the strength of the signal from the generator.




Fig. 1

left is adjusted by set screw No. 1. The next push button by set screw No. 2 and the remaining push buttons in order.

1. Remove the 7C6 A. F. tube from its socket and insert the aligning adaptor, then replace the tube in the adaptor. Connect the negative terminal of the vacuum tube voltmeter to the wire which protrudes from the side of the adaptor. Attach the positive terminal of the voltmeter to the chassis.

2. Turn the receiver on and set the tuning range disc to "Broadcast" (Manual Tuning).

3. Set up the Model 077 Station Setter about 3 feet from the receiver and connect a loop constructed out of about 6 feet of wire to the high and ground output jacks of the signal generator. Turn the output controls to maximum and set the modulation control to "MOD. ON". Manually tune in the first station to be set up on push button No. 1. After doing this set the indicator of the 077 Signal Generator to the frequency of the station being received. As the indicator approaches the frequency of the station a whistle will be heard; leave the indicator at this point. Turn the receiver tuning range disc to "Push Button" and press in No. 1 button. Using the insulated screw driver turn the No. 1 "Osc." screw until the broadcast station identified by the signal generator is heard; at this point, turn the indicator of the signal generator away from the frequency of the station. Readjust No. 1 "Osc." and "Ant." screws for maximum deflection of the vacuum tube voltmeter pointer. Station No. 1 is now adjusted properly. After setting up the first station the same procedure as outlined above is used for the remaining stations.

When this model is to be set up to receive the sound of a television program tuned in by the special type Philco television sets or when it is to be used in conjunction with a Philco Record Player, push-button No. 1 should be used. To tune in these programs, the same procedure as given for ordinary broadcast stations as outlined above is used.

PHILCO RÁDIO & TELEVISION CORP.

MODEL 40-165

MODELS 40-180,
40-185, 40-190

MODEL 40-165 PRODUCTION CHANGES

Run 1 — Beginning with Run 1 receivers the converter tube was changed from a 7J7 loctal type to a 6J8G octal type. Tube sockets change from 27-6129 loctal to 27-6120 octal.

Run 2 — Additional condenser Part No. 30-4123 added across condenser (54) to reduce hum.

Run 3 — 6J8G converter tube socket Part No. 27-6120 reversed 180 degrees to prevent oscillation at 18 M. C. This reverses the position of the socket as wired in Run 1 receiver.

Run 4 — Converter tube changed back to a 7J7 loctal type from a 6J8G tube. This change makes the set correspond to the circuit diagram in the Service Bulletin.

S. W. loop assembly in Model 40-165K is Part No. 38-9968. This differs from loops used in the "F" cabinet.

For other data, see Index

MODELS 40-180, 40-185, 40-190

In general, these models are similar with the exception of the number of tubes used and the cabinet design. Model 40-180 employs a seven tube receiver. Models 40-185 and 40-190 employ eight tube receivers assembled in different type cabinets.

PRODUCTION CHANGES

MODEL 40-180

Run 4 — Beginning with Run 4 receivers the converter tube was changed from a type 7J7 loctal to a 6J8G octal type.

Run 5 — A new resistor Part No. 33-115339 not shown on diagram of Service Bulletin was added in series with plates of the 6J8G tube. This change made to improve oscillator action at 18 M. C. Cathode resistor (34) changed from Part No. 33-115339 carbon type to Part No. 33-115336 wirewound.

MODEL 40-185

Run 4 — Beginning with Run 4 receivers the converter tube was changed from a type 7J7 loctal to a 6J8G octal type. Tube sockets changed from Part No. 27-6129 to Part No. 27-6120.

MODEL 40-190

Run 4 — Beginning with Run 4 receivers the converter tube was changed from a type 7J7 loctal to a 6J8G octal type. Tube sockets changed from Part No. 27-6120 to Part No. 27-6120.

Run 5 — A new resistor Part No. 33-115339 not shown on diagram of the Service Bulletin was added in series with the plates of the 6J8G tube. This change was made to improve oscillation action at 18 M. C. Cathode resistor (34) changed from Part No. 33-115339 carbon type to Part No. 33-115336 wirewound.

MODELS 40-180, 40-190

To prevent oscillation at the low end of the broadcast band the 2nd I. F. transformer (37) changed from Part No. 32-3242 to Part No. 32-3249.

The physical location of condenser (4) as shown in Fig. 2 of the Service Bulletin has been changed to prevent oscillation at 540 K. C. The condenser is now wired to a three lug wiring panel between the range switch and the volume control. The antenna lead is connected to one lug of the panel. This change is made on all sets marked Run No. 9, Model 40-180 and Run No. 10, Model 40-190.

MODELS 40-185, 40-190

Beginning with Run "B" receivers the converter tube is changed from a type 6J8G octal to a 7J7 loctal. Tube sockets changed from Part No. 27-6120 to 27-6129 loctal.

This change reverses the change made on Run "A" receivers.

MODELS 40-180, 40-185, 40-190





FIG. 1 — Part locations underside of chassis

SCHE. No.	PART DESCRIPTION	SCHE. No.	PART DESCRIPTION	SCHE. No.	PART DESCRIPTION	PART No.
1	Loop Ass'y. (Broadcast).	38-9880	32	Tubular Cond. (.05 mfd.)	30-4519	64 Line Cond. (Bakelite, .01-.01 mfd.) 390-300
1A	Mica Cond. (250 mmfd.).	61-0033	33	Tubular Cond. (.2 mfd.)	30-4536	65 Pilot Lamp.....
1B	Resistor (10,000 ohms, $\frac{1}{2}$ watt)	33-310339	34	Resistor (150 ohms, $\frac{1}{2}$ watt)	33-115339	66 Wave Switch.....
2	Loop Ass'y. (Short Wave)	38-9884	35	Resistor (33,000 ohms, $\frac{1}{2}$ watt)	33-333339	
3	Compensator.....	31-6308	36	Resistor (1000 ohms, $\frac{1}{2}$ watt)	33-210339	
4	Mica Cond. (.5 mmfd.)	30-1097	37	2nd I. F. Trans. Ass'y.	32-3246	
5	Mica Cond. (1250 mmfd.)	5886	38	Tubular Cond. (.01 mfd.)	30-4479	
6	Mica Cond. (250 mmfd.)	61-0033	39	Resistor (470,000 ohms, $\frac{1}{2}$ watt)	33-447339	
7	Mica Cond. (390 mmfd.)	33-139339	40	Resistor (33,000 ohms, $\frac{1}{2}$ watt)	33-333339	
8	Tubular Cond. (.05 mfd.)	30-4444	40A	Tubular Cond. (.01 mfd.)	30-4479	
9	Resistor (1.0 meg., $\frac{1}{2}$ watt)	33-510339	41	Volume Control (2.0 meg.)	33-5273	
10	Tubular Cond. (.05 mfd.)	30-4123	42	Tubular Cond. (.01 mfd.)	30-4479	
11	Resistor (33,000 ohms, $\frac{1}{2}$ watt)	33-333339	43	Resistor (2.2 mega, $\frac{1}{2}$ watt)	33-522339	
12	Resistor (10,000 ohms, $\frac{1}{2}$ watt)	33-310339	44	Resistor (10.0 mega, $\frac{1}{2}$ watt)	33-610339	
13	R. F. Coupling Trans.	32-3194	45	Mica Cond. (110 mmfd.)	30-1130	
14	Mica Cond. (.100 mmfd.)	30-1128	46	Tubular Cond. (.01 mfd.)	30-4572	
15	Resistor (47,000 ohms, $\frac{1}{2}$ watt)	33-347339	47	Resistor (220,000 ohms, $\frac{1}{2}$ watt)	33-422339	
16	Resistor (4700 ohms, $\frac{1}{2}$ watt)	33-247339	48	Resistor (1.0 mega, $\frac{1}{2}$ watt)	33-510339	
17	Tubular Cond. (.05 mmfd.)	30-4123	49	Resistor (470,000 ohms, $\frac{1}{2}$ watt)	33-447339	
18	Oscillator Trans.	32-3195	50	Tubular Cond. (.003 mfd.)	30-4469	
19	Compensator (2 Section)	31-6298	51	Tone Control & On-Off Switch	33-5314	
20	Mica Cond. (.5300 mmfd.)	30-1134	52	Tubular Cond. (.01 mfd.)	30-4572	
21	Tuning Cond. Ass'y.	31-2391	53	Resistor (3900 ohms, $\frac{1}{2}$ watt)	33-239339	
22	Mica Cond. (.250 mmfd.)	61-0033	54	Resistor (470,000 ohms, $\frac{1}{2}$ watt)	33-447339	
23	Silver Mica Cond. (.370 mmfd.)	30-1110	55	Tubular Cond. (.003 mfd.)	30-4469	
24	Silver Mica Cond. (.370 mmfd.)	30-1110	56	Output Trans.	32-8053	
25	Resistor (33,000 ohms, $\frac{1}{2}$ watt)	33-333339	57	Cone & Voice Coil Ass'y		
26	Push Button Switch.....	42-1489		(Spkr. Part No. 36-1479-2)	36-4089	
27	Padlock Strip (Push Buttons)	31-6399		(Spkr. Part No. 36-1479-4)	36-4111	
28	Coil Strip Ass'y	58		Electrolytic Cond. (16 mfd., 200 V.)	30-2406	
28A	Coil No. 1	59		Resistor (15 ohms, $\frac{1}{2}$ watt)	33-015351	
28B	Coil No. 2	540-1060	K. C.	Resistor (150 ohms, 1 watt)	33-115451	
28C	Coil No. 3	60		Electrolytic Cond. (12 mfd.,		
28D	Coil No. 4	61		350 V.)	30-2405	
28E	Coil No. 5	650-1110	K. C.	Field Coil (Replace Speaker,		
28F	Coil No. 6	62		Part No. 36-1479		
28G	Coil No. 7	920-1600	K. C.	Power Transformer		
29	Resistor (4700 ohms, $\frac{1}{2}$ watt)	33-247339	63	(115 Volts, 50 to 60 Cycle)	32-8052	
30	1st I. F. Trans. Ass'y.	32-3245		(115 Volts, 25 Cycle)	32-8086	
31	Tubular Cond. (.05 mfd.)	30-4123		(120/240 Volts, 60 Cycle)	32-8092	

MISCELLANEOUS PARTS

Bezel Ass'y.....	40-6489
Bezel Gasket.....	27-9175
Cable & Plug (Power Supply)	L-3199
Cabinet Model 40-180.....	10372B
Cabinet Model 40-185.....	10400A
Cabinet Model 40-190.....	10391A
Clip (Coil mtg.)	28-5003
Dial.....	27-5508
Dial Tuning Drum Ass'y	38-9856
Drive Cord Ass'y.....	31-2383
Knobs (Tuning, Tone, Volume, Wave Switch)	27-1332
Knobs (Pushbuttons)	27-4852
Pilot Lamp Socket Ass'y	38-9607
Pointer.....	56-1516
Screws (Bezel mtg.)	W-1834FG1
Spring (Drive Cord)	28-8913
Spring (Dial Background Plate mtg.)	28-8908
Socket (Type 84 Tube)	27-6035
Socket (Type 41 Tube)	27-0036
Socket (Loktal, Type 717 Tube)	27-6129
Speaker.....	27-6131
Tab (Dial)	27-5530
Tab (Television)	27-9449
Tab Kit.....	40-6475
Tuning Shaft Ass'y.....	38-9874
Washer	
"C" Type, Tuning Shaft Ass'y	28-2043
(Spring Type, Tuning Shaft Ass'y)	28-4186

PHILCO RADIO & TELEVISION CORP.



voltages indicated were measured with a Philco Model 027 Voltmeter (1000 ohms per volt) — Power supply 115 volts, 60 cycle — Volume control minimum — No signal being received — Range switch "Bridge."


Schematic, Socket, Trimmers PHILCO RADIO & TELEV. CORP.

MODELS 40-150, 40-155
MODELS 40-180, 40-185
40-190

POWER SUPPLY: 115 Volts, 25 and 60 cycle AC.

POWER CONSUMPTION: 60 watts.

AUDIO OUTPUT: 2 watts.



©John F. Rider, Publisher

MODELS 40-150, 40-155
MODELS 40-180, 40-185, 40-190

PHILCO RADIO & TELEV. CORP.

Alignment

Models 40-150 and 40-155

TYPE OF CIRCUIT: Models 40-180, 40-185 and 40-190 are Electric Push-button and dial tuned radios incorporating the new Philco Built-in Super Aerial system which eliminates an outside aerial and reduces local static interference to a minimum. The models are also designed to receive the sound of a television program tuned in by special type Philco Television Sets.

PHILCO BUILT-IN SUPER AERIAL SYSTEM—Included in the built-in super aerial system is a statically shielded loop for broadcast band reception and a short wave receiving loop. A feature of the built-in broadcast band statically shielded loop is that it may be turned to the position in which it picks up a minimum amount of interference, or if interference is not

present the loop may be set in the position where best reception is obtained.

In general, these models are similar with the exception of the number of tubes used and cabinet design. Model 40-180 employs a seven tube receiver. Models 40-185 and 40-190 employ eight tube receivers assembled in different type cabinets.

Each model is equipped with eight electric tuning push buttons for automatically selecting stations. Six of the push buttons are used for broadcast stations, one for selecting dial tuning and one push button may be set up for use with a Philco wireless Record Player or the sound program tuned in by special Philco Television Sets.

Model 40-150 employs seven (7) tubes and Model 40-155, eight (8) tubes.

Aligning of Compensating Condensers Equipment Required

(1) *Signal Generator.* In order to properly adjust this receiver an accurately calibrated signal generator such as Philco Model 077 is required. This signal generator covers a frequency range of 540 to 36,000 K. C. (2) *Indicating Device.* To obtain maximum signal strength and accurate adjustment of the padders a vacuum tube voltmeter and circuit tester such as Philco Models 027 and 028 is

recommended. When using the vacuum tube voltmeter, an aligning adapter, Philco Part No. 45-2767, is necessary for connecting to the A. V. C. circuit. These testers also contain an audio output meter which may also be used as an indicating device. (3) *Aligning Tools.* Fiber handle screw driver, Philco Part No. 45-2610, and fiber wrench, Philco Part No. 7696.

Connecting Aligning Instruments

VACUUM TUBE VOLTMETER—To use the vacuum tube voltmeter as an alignment indicator make the following connections:

1. Adjusting I. F. Circuit.

Remove the 1232 R. F. tube from its socket and insert the aligning adaptor, then replace the tube in the adaptor. Connect the negative terminal of the vacuum tube voltmeter to the wire (light color) which protrudes from the side of the adaptor. Attach the positive terminal of the voltmeter to the black wire.

2. Adjusting R. F. Circuit.

To adjust the R. F. circuit, the aligning adaptor is inserted in the 7C6 A. F. tube socket. The vacuum tube voltmeter remains connected to the adaptor as given in the above paragraph.

With the voltmeter connected in this manner a very sensitive indication of the A. V. C. voltage is obtained when the padders are adjusted. If an audio output meter is used, connect it to the plate

and socket terminals of the 41 output tube and adjust the output meter for the 0 to 30 A. C. scale.

After connecting the aligning indicator, adjust the compensators in the order as shown in the tabulation below. Locations of the compensators are shown on the schematic diagram, page No. 2. If the output meter pointer goes off scale when adjusting the compensators, reduce the strength of the signal from the generator.

SIGNAL GENERATOR: When adjusting the I. F. padders, the high side of the signal generator is connected through a .1 mfd. condenser to terminal No. 1 of the loop terminal panel at the rear of the chassis. The ground or low side of the signal generator is connected to the chassis of the receiver.

When aligning the R. F. padders a loop is made from a few turns of wire and connected to the signal generator output terminals; the loop is then placed two or three feet from the loop in the cabinet. Do not remove the receiver loop from the cabinet. It is necessary when adjusting the padders that the receiver be left in the cabinet.

Models 40-150, 40-155 40-180 - 185 - 190

Operations	SIGNAL GENERATOR		RECEIVER			Remarks
	Output Connections	Dial Frequency	Dial Frequency	Control Settings	Adjust Compensators for Max. Signal	
1	High Side to No. 1 Ter. Loop Panel	I. F. 455 K. C.	580 K. C. No Signal	Range Sw. "Brdest." Volume "Max." Push-Button "Dial"	37A, 30, 30A	See Note A.
2	Use Loop on Generator	18 M. C.	18 M. C.	Range Sw. "SW." Volume "Max." Push-Button "Dial."	21A	Note B. Note D.
3	Use Loop on Generator	1400 K. C.	1400 K. C.	Range Sw. "Brdest." Volume "Max."	19A, 21B	
4	Use Loop on Generator	580 K. C.	580 K. C.	Range Sw. "Brdest." Volume "Max."	19	Roll Cond. Note C.
5	Use Loop on Generator	1400 K. C.	1400 K. C.	Range Sw. "Brdest." Volume "Max."	19A, 21B	Roll Cond. Note C.
6	Use Loop on Generator	18 M. C.	18 M. C.	Range Sw. "SW."	3	Roll Cond. Note C.

NOTE A—A "Dummy Antenna" consisting of a .1 mfd. condenser is connected in series with the signal generator output lead (high side).

NOTE B—DIAL CALIBRATION: In order to adjust the receiver correctly the dial must be aligned to track properly with the tuning condenser. To adjust the dial, proceed as follows: With the tuning condenser closed (maximum capacity), set the dial pointer on the greatest left index line at the low frequency end of the broadcast scale. The arrangement of the drive cable in this position is shown in the schematic diagram.

NOTE C—When adjusting the low frequency compensator of Range One (Broadcast) or the antenna and R. F. compensators of the high frequency tuning ranges; the receiver Tuning Condenser must be adjusted (rolled) as follows: First tune the compensator for maximum output, then vary the tuning condenser of the receiver for maximum output. Now turn the

compensator slightly to the right or left and again vary the receiver tuning condenser for maximum output. This procedure of first setting the compensator and then varying the tuning condenser is continued until there is no further gain in output reading.

NOTE D—To accurately adjust the high frequency oscillator compensator to the fundamental instead of the image signal, turn the oscillator compensator to the maximum capacity position (clockwise). From this position slowly turn the compensator counter-clockwise until a second peak is obtained on the output meter. Adjust the compensator for maximum output at this second peak.

If the above procedure is correctly performed, the image signal will be found (much weaker) by turning the receiver dial 910 K. C. below the frequency being used on any high frequency range.

Socket, Trimmers
Chassis, Parts

PHILCO RADIO & TELEV. CORP.

MODELS 40-150, 40-155

MODELS 40-180, 40-185

40-190

- PHILCO TUBES USED:**
- MODEL 40-150, 40-180—1232, R. F.; 7J7, Converter; 7B7, I. F.;
7C6, Second Detector and First Audio; two 41, Audio Power Outputs;
84, Rectifier.
- MODEL 40-155, 40-185 AND 40-190—1232, R. F.; 7J7, Converter;
7B7, I. F.; 7A6, Detector; 7C6, First Audio; two 41, Power Outputs;
84, Rectifier.




Fig. 2—Part locations underside of chassis

Replacement Parts—Models 40-180, 40-185, 40-190

Sch. No.	Description	Part No.
1	Loop Ass'y (Broadcast)	38-9880
1A	Mica Cond. (250 mmfd.)	61-0033
1B	Resistor (10,000 ohms, $\frac{1}{2}$ watt)	33-310339
2	Loop Ass'y (Short Wave)	38-9884
3	Compensator	31-6308
4	Mica Cond. (.5 mmfd.)	30-1097
5	Mica Cond. (1250 mmfd.)	5886
6	Mica Cond. (250 mmfd.)	61-0033
7	Resistor (.390 ohms, $\frac{1}{2}$ watt)	33-139339
8	Tubular Cond. (.05 mfd.)	30-4444
9	Resistor (1.0 meg, $\frac{1}{2}$ watt)	33-510339
10	Tubular Cond. (.05 mfd.)	30-4123
11	Resistor (.33,000 ohms, $\frac{1}{2}$ watt)	33-333339
12	Resistor (10,000 ohms, $\frac{1}{2}$ watt)	33-310339
13	R. F. Coupling Trans.	32-3194
14	Mica Cond. (100 mmfd.)	30-1128
15	Resistor (47,000 ohms, $\frac{1}{2}$ watt)	33-347339
16	Resistor (4700 ohms, $\frac{1}{2}$ watt)	33-247339
17	Tubular Cond. (.05 mfd.)	30-4123
18	Oscillator Trans.	32-3195
19	Compensator (2 Section)	31-6298
20	Mica Cond. (3300 mmfd.)	30-1134
21	Tuning Cond. Ass'y	31-2391
22	Mica Cond. (250 mmfd.)	61-0033
23	Silver Mica Cond. (370 mmfd.)	30-1110
24	Silver Mica Cond. (370 mmfd.)	30-1110
25	Resistor (.33,000 ohms, $\frac{1}{2}$ watt)	33-333339
26	Push Button Switch	42-1489
27	Padder Strip (Push Buttons)	31-6299
28	Coil Strip Ass'y	
28A	Coil No. 1	
28B	Coil No. 2	{ 540-1060 K. C.
28C	Coil No. 3 32-3042
28D	Coil No. 4	{ 650-1110 K. C.
28E	Coil No. 5 32-3042
28F	Coil No. 6	{ 920-1600 K. C.
29	Coil No. 7 32-3041
30	Resistor (4700 ohms, $\frac{1}{2}$ watt)	33-247339
31	1st I. F. Trans. Ass'y	32-3245
32	Tubular Cond. (.05 mfd.)	30-4123
33	Tubular Cond. (.05 mfd.)	30-4519
34	Tubular Cond. (.2 mfd.)	30-4536
35	Resistor (150 ohms, $\frac{1}{2}$ watt)	33-115339
36	Resistor (33,000 ohms, $\frac{1}{2}$ watt)	33-333339
37	Resistor (1000 ohms, $\frac{1}{2}$ watt)	33-210339
38	2nd I. F. Trans. Ass'y	32-3245
39	Tubular Cond. (.01 mfd.)	30-4479
40	Resistor (470,000 ohms, $\frac{1}{2}$ watt)	33-447339
41	Resistor (33,000 ohms, $\frac{1}{2}$ watt)	33-333339
42	Tubular Cond. (.01 mfd.)	30-4479
43	Tubular Cond. (.01 mfd.)	30-522339
44	Resistor (2.2 megs, $\frac{1}{2}$ watt)	33-522339
45	Resistor (10.0 megs, $\frac{1}{2}$ watt)	33-610339
	Mica Cond. (110 mmfd.)	30-1130

Models 40-150, 40-155
Parts listed below apply to Models
40-150, 40-155 only. For parts not
found below refer to list for Models
40-180, 40-185 and 40-190 above.

Sch. No.	Description	Part No.
1	Loop Ass'y (Broadcast)	38-9894
1C	Compensator Ass'y	31-6318
4	Mica Cond. (5 mmfd.)	30-1120
5B	Mica Cond. (1500 mmfd.)	7137
5A	Ant. Loading Trans.	32-3290
B	Tubular Cond. (.05 mfd.)	30-4519
21	Tuning Cond. Ass'y	31-2401
33	Tubular Cond. (.2 mfd.)	30-4587
38	Tubular Cond. (.01 mfd.)	30-4581
40A	Tubular Cond. (.01 mfd.)	30-4581
42	Tubular Cond. (.01 mfd.)	30-4581
55B	Tubular Cond. (.006 mfd.)	30-4504
55A	Tubular Cond. (.006 mfd.)	30-4504
57	Cone and Voice Coil Ass'y (Spkr. Part No. 36-1483-2)	
62	Field Coil (Replace Spkr. Part No. 36-1483)	32-8065
63	Power Trans. (110 Volts, 60 Cycles)	36-1483
	Speaker	