

# PHILCO . . . . . Model 39-25, Code 121



## SERVICE BULLETIN No. 303 for members of RADIO MANUFACTURERS SERVICE

A PHILCO Service Plan

### SPECIFICATIONS

**TYPE OF CIRCUIT:** A. C. operated; superheterodyne circuit with two tuning ranges, covering standard broadcast (540 K. C. to 1720 K. C.) and short wave (4.9 M. C. to 18.0 M. C.) frequencies; Automatic Volume Control; and pentode output.

The receiver is designed to operate from a "Philco Safety Aerial," part No. 40-6371. This aerial system should be used to obtain maximum performance from the receiver.

**POWER SUPPLY:** Voltage—115 volts. Frequency 50-60 cycles. Power consumption 45 watts.


**INTERMEDIATE FREQUENCY:** 470 K. C.

**TUNING RANGES:** 540 K. C. to 1720 K. C.; 4.9 M. C. to 18.0 M. C.

**PHILCO TUBES USED:** 1-6A8G, 1st detector and oscillator; 1-78, I. F.; 1-75, 2nd detector, Automatic Volume Control, and 1st audio; 1-41, Output; and 1-84, Rectifier.

**TUNING MECHANISM:** Pulley and cable drive for Manual tuning. Electric Push-Button for Automatic tuning.

**CABINETS:** Types "T" and "XF."



**Fig. 1. Socket Voltage—Underside of Chassis**  
The voltages indicated by arrows were measured with a Philco 027 Circuit Tester, which contains a sensitive voltmeter. Volume Control at minimum—Tuning Condenser set for no signal—line voltage 115 A. C.

### Adjusting Push-Button Tuning to Stations

These detailed instructions have been prepared to make sure the correct procedure is followed in setting the stations on the Philco Electric Push-Button Tuning models. The work requires the use of a Philco Model 077 Station Setter and a part No. 27-7059 Insulated Screw Driver.

(A) Select eight of the most popular stations received in the locality and remove their call letters from the call letter sheets supplied. Place the call letters in the windows above the buttons, making sure that each respective button covers the frequency of the station for which it is to be used. The frequency range of the circuits are as follows:

Circuits	Frequency Range
1 and 2	540 to 1030 kilocycles
3 and 4	670 to 1160 kilocycles
5 and 6	900 to 1470 kilocycles
7 and 8	1170 to 1600 kilocycles

These numbers are stamped on the unit as seen from the rear. Looking at the front of the cabinet the numbers read from left to right.

(B) Connect the aerial and ground to the "ANT" and "GND" terminals of the receiver.

(C) Turn the receiver Tuning Range Selector to position two ("Manual Tuning") and tune the receiver to the station to be set on the first button.

(D) Plug the output leads of the Station Setter into the "High" and "Gnd" jacks, and turn the output controls to maximum.

Turn the modulation control to "Modulation Off." Connect the output lead of the Station Setter to the "ANT" and "GND" terminals of the receiver and tune to the frequency of the station being received. As the indicator is slowly tuned through the frequency of the station there will be two points at which a high pitched swish will be heard, one above and one below the frequency of the station. When the indicator is on the frequency of the station, minimum high pitched swish will be heard.

(E) Set the modulation control of the Station Setter for "Modulation On." The modulated signal of the Station Setter will then be heard through the receiver.

(F) Turn the receiver Tuning Range Selector to position one (Automatic Tuning) and push in the first button. Using the Part No. 27-7059 Insulated Screw Driver, turn the number 1 "OSC" screw until the modulated signal of the Station Setter is tuned in to maximum volume. Then adjust the number 1 "ANT" screw for maximum signal.

(G) Remove the output lead of the Philco Station Setter from the "ANT" terminal of the receiver and turn its indicator off the frequency of the station. The program of the desired station will then be heard on the receiver.

(H) With the volume of the receiver low, slowly turn the number 1 "OSC" back and forth until maximum output is received. Repeat the same procedure for the number 1 "ANT" screw.

After setting up the first station, the same procedure given under (C) to (H) is used for the other stations.




Fig. 2. Schematic Diagram, Model 39-25, Code 121




Fig. 3. Part Locations, Underside of Chassis

## REPLACEMENT PARTS—MODEL 39-25, CODE 121

Schem. No.	Description	Part No.	Schem. No.	Description	Part No.
1	Antenna Transformer (short wave)	32-3027	42	Resistor (280 ohms, wire wound)	33-128431
2	Antenna Transformer (broadcast)	32-3026	43	Resistor (70 ohms, 1/2 watt)	33-070339
3	Tubular Condenser (.05 mf.)	30-4519	44	Push-Button Switch	42-1446
4	Tuning Condenser Assembly	31-2267	45	Compensator Strip Assembly	31-6256
5	Dual Padder Unit	31-6255	45A	Compensator, No. 1, 540-1030 K. C.	31-6274
6	Oscillator Transformer	32-3028	45B	Compensator, No. 2, 540-1030 K. C.	31-6274
7	Condenser (250 mmf., mica)	30-1032	45C	Compensator, No. 3, 670-1160 K. C.	31-6276
8	Condenser (4500 mmf., mica)	30-1109	45D	Compensator, No. 4, 670-1160 K. C.	31-6276
9	Resistor (51,000 ohms, 1/2 watt)	33-351339	45E	Compensator, No. 5, 900-1470 K. C.	31-6278
10	Condenser (370 mmf., silver plated mica)	30-1110	45F	Compensator, No. 6, 900-1470 K. C.	31-6278
11	Condenser (370 mmf., silver plated mica)	30-1110	45G	Compensator, No. 7, 1170-1600 K. C.	31-6280
12	1st I. F. Transformer Assembly	32-3018	45H	Compensator, No. 8, 1170-1600 K. C.	31-6280
13	Condenser (.1 mf., tubular)	30-4455	46	Electric Tuning Coil Assembly (complete)	32-3031
14	Resistor (32,000 ohms, 1/2 watt)	33-332339	46A	Osc. Coil, No. 1, 540-1030 K. C.	32-3042
15	Resistor (3000 ohms, 1/2 watt)	33-230339	46B	Osc. Coil, No. 2, 540-1030 K. C.	32-3042
16	Resistor (5000 ohms, 1/2 watt)	33-250339	46C	Osc. Coil, No. 3, 670-1160 K. C.	32-3042
17	Electrolytic Condenser (16 mf., 250 V.)	30-2331	46D	Osc. Coil, No. 4, 670-1160 K. C.	32-3042
18	Electrolytic Condenser (16 mf., 250 V.)	30-2331	46E	Osc. Coil, No. 5, 900-1470 K. C.	32-3041
19	Condenser (110 mmf., mica)	30-1031	46F	Osc. Coil, No. 6, 900-1470 K. C.	32-3041
20	2nd I. F. Transformer Assembly	32-3030	46G	Osc. Coil, No. 7, 1170-1600 K. C.	32-3041
21	Resistor (51,000 ohms, 1/2 watt)	33-351339	46H	Osc. Coil, No. 8, 1170-1600 K. C.	32-3041
22	Volume Control (500,000 ohms)	33-5289	47	Range Switch	42-1445
23	Condenser (.05 mf., tubular)	30-4444	48	Pilot Lamp	34-2210
24	Resistor (1 meg., 1/2 watt)	33-510339		Bezel Assembly	40-6365
25	Resistor (2 megs., 1/2 watt)	33-520339		Bezel Gasket	27-9175
26	Condenser (.05 mf., tubular)	30-4518		Bezel Screw	W-1834
27	Condenser (.003 mf., tubular)	30-4469		Cable (speaker)	41-3443
28	Resistor (4.0 megs., 1/2 watt)	33-540339		Cable (power)	L-2778
29	Condenser (250 mmf., mica)	30-1032		Dial Scale	27-5403
30	Condenser (.01 mf., tubular)	30-4572		Dial Spring	28-8908
31	Resistor (70,000 ohms, 1/2 watt)	33-370339		Dial Pointer	28-5941
32	Resistor (750,000 ohms, 1/2 watt)	33-475339		Dial Drive Cord Assembly	31-2269
33	Output Transformer	32-7978		Dial Drive Spring	28-8913
34	Voice Coil and Cone Assembly (for "T" Speaker, part No. 36-1439)	36-4087		Dial Tuning Shaft Assembly	31-2260
	(for "XF" Speaker, part No. 36-1437)	36-4088		Dial Tuning Drum	31-2281
35	Condenser (.03 mf., tubular)	30-4449		Knob	27-4332
36	Condenser (.006 mf., tubular)	30-4445		Socket (5 Prong)	27-6035
37	Tone Control and On-Off Switch	42-1443		Socket (6 Prong)	27-6036
38	Condenser (.01 mf.-.01 mf., bakelite)	3903-DG		Socket (7 Prong)	27-6099
39	Power Transformer	32-7976		Pilot Lamp Socket Assembly	38-9607
40	*Field Coil for Speaker, part No. 36-1439			Pushbutton	27-4759
	*Field Coil for Speaker, part No. 36-1437			Speaker (T Cabinet)	36-1439
41	Electrolytic Condenser (8 mf., 400 V.)	30-2330		Speaker (XF Cabinet)	36-1437

\* Replace Speaker.

**Alignment of Compensators**

**EQUIPMENT REQUIRED:** (1) Signal Generator; Philco Model 077 Signal Generator which has a fundamental frequency range from 115 to 36,000 K. C. is the correct instrument for this purpose. (2) Output meter, Philco Model 027 Circuit Tester, incorporates a sensitive output meter and is recommended. (3) Philco Fiber Handle Screw Driver, part No. 27-7059, and Fiber Wrench, part No. 3164.

**OUTPUT METER:** The Philco 027 Output Meter is connected to the plate and cathode terminals of the Type 41 tube. Set the meter to use the 0-30 volt scale. After connecting the output meter adjust compensators in the order as given below.




Fig. 4. Locations of Compensators

Operations in Order	Signal Generator			Receiver			Special Instructions
	Output Connections to Receiver	Dummy Antenna (Note A)	Dial Setting	Dial Setting	Control Settings	Adjust Compensators in-Order	
1	6A8G Grid	.1 mf.	470 KC	580 KC	Vol. Cont. max.	(20A) (12B) (12A)	
2	Ant. Ter.	100 mmf.	18.0 MC	18.0 MC	Vol. Cont. max.	(4B)	See Note B
3	Ant. Ter.	100 mmf.	1550 KC	1550 KC	Vol. Cont. max.	(5) (4A)	
4	Ant. Ter.	100 mmf.	580 KC	580 KC	Vol. Cont. max.	(5A)	
5	Ant. Ter.	100 mmf.	1550 KC	1550 KC	Vol. Cont. max.	(5)	

**NOTE A**—The "Dummy Antenna" consists of a condenser connected in series with the signal generator output lead (high side). Use the capacity as specified in each step of the above procedure.

**NOTE B—DIAL CALIBRATION:** In order to adjust the receiver correctly the dial pointer must be aligned to track properly with the tuning condenser. To adjust the dial proceed as follows: With the tuning condenser closed, set the dial pointer on the extreme left index line at the low frequency end of the scale.

**PHILCO RADIOS will give original quality performance ONLY when Genuine PHILCO REPLACEMENT PARTS are used.**

**PHILCO RADIO AND TELEVISION CORPORATION**  
**Parts and Service Division**  
**Philadelphia, Pa.**