

# Pre-WWII FM Receiver Channel Frequency Tuning Chart

L Selection	
New Band	Old Band
88.1	49.9
88.3	49.7
88.5	49.5
88.7	49.3
88.9	49.1
89.1	48.9
89.3	48.7
89.5	48.5
89.7	48.3
89.9	48.1
90.1	47.9
90.3	47.7
90.5	47.5
90.7	47.3
90.9	47.1
91.1	46.9
91.3	46.7
91.5	46.5
91.7	46.3
91.9	46.1
92.1	45.9
92.3	45.7
92.5	45.5
92.7	45.3
92.9	45.1
93.1	44.9
93.3	44.7
93.5	44.5
93.7	44.3
93.9	44.1
94.1	43.9
94.3	43.7
94.5	43.5
94.7	43.3
94.9	43.1
95.1	42.9
95.3	42.7
95.5	42.5
95.7	42.3
95.9	42.1

M Selection	
New Band	Old Band
94.1	49.9
94.3	49.7
94.5	49.5
94.7	49.3
94.9	49.1
95.1	48.9
95.3	48.7
95.5	48.5
95.7	48.3
95.9	48.1
96.1	47.9
96.3	47.7
96.5	47.5
96.7	47.3
96.9	47.1
97.1	46.9
97.3	46.7
97.5	46.5
97.7	46.3
97.9	46.1
98.1	45.9
98.3	45.7
98.5	45.5
98.7	45.3
98.9	45.1
99.1	44.9
99.3	44.7
99.5	44.5
99.7	44.3
99.9	44.1
100.1	43.9
100.3	43.7
100.5	43.5
100.7	43.3
100.9	43.1
101.1	42.9
101.3	42.7
101.5	42.5
101.7	42.3
101.9	42.1

H Selection	
New Band	Old Band
100.1	49.9
100.3	49.7
100.5	49.5
100.7	49.3
100.9	49.1
101.1	48.9
101.3	48.7
101.5	48.5
101.7	48.3
101.9	48.1
102.1	47.9
102.3	47.7
102.5	47.5
102.7	47.3
102.9	47.1
103.1	46.9
103.3	46.7
103.5	46.5
103.7	46.3
103.9	46.1
104.1	45.9
104.3	45.7
104.5	45.5
104.7	45.3
104.9	45.1
105.1	44.9
105.3	44.7
105.5	44.5
105.7	44.3
105.9	44.1
106.1	43.9
106.3	43.7
106.5	43.5
106.7	43.3
106.9	43.1
107.1	42.9
107.3	42.7
107.5	42.5
107.7	42.3
107.9	42.1